PUTTING ON A FEMIDOM



Reference : L41



Includes labia and vagina. It is deliberately simplified to facilitate the understanding and implementation of a female condom (supplied without a condom).



15 Av. des grenots - 91150 Etampes Tel. : +33 (0)1 69 92 26 72 - Fax : +33 (0)1 69 92 26 74 - Email : info@sordalab.com