

BATTERY TESTER

Reference : TESTPIL



Displays the battery status as a bargraph.

- For models: 1.5V type AAA or LRO03, AA or LR06, C or LR14, D or LR20, 9V 6F22 or E, 3V CR2, 3V CR-V3, 6V 2CR5, 6V CR-P2, works for most 1.5V type button batteries.
- Dimensions: 120 x 90 x 20mm.