

MANUAL VACUUM PUMP WITH BELL AND MANOMETER

Reference : CLOPOMP



All in one for quick installation

Hand pump and integrated pressure gauge

The bell is calibrated to be accurately positioned on the plate. On the top of the bell, a valve allows you to adjust or break the vacuum, and a pressure gauge dial to measure the internal pressure.

The plate has a circular seal ensuring a perfect seal with the bell. The base contains the pump for extracting air from the bell.

The plate can also be used without the bell as a simple vacuum pump with other accessories (not supplied). Simply unscrew the cap on the plate and connect the device in question.

Technical characteristics:

- Manometer: vacuum limit of 330 mbar (250 mmHg)
- Clear vacuum bell
- Depressurisation valve
- Dimensions: Ø 200 mm x 250 mm